



- NOTES:
- 1. CONSULT THE RESPECTIVE MANUFACTURER OF THE SELF-FLASHING METAL CURB FOR PROPER SECUREMENT.
- 2. WATER CUT-OFF MASTIC MUST BE HELD UNDER CONSTANT COMPRESSION.
- 3. USE DETAIL U-15F TO ACHIEVE SUFFICIENT COVERAGE OF METAL FLANGE AT CORNERS.
- 4. IF THE VERTICAL SPLICE ON THE CURB FLASHING IS NOT LOCATED AT THE CORNER, USE DETAIL U-2C FOR EPDM MEMBRANE SPLICES AT ANGLE CHANGES.

