

NOTES:

- 1. FASTEN COATED METAL FLASHING TO WOOD NAILERS USING 1-1/2" (4cm) MIN. RING SHANK NAILS SPACED 6" (15cm) ON CENTER AND STAGGERED APPROX. 1/2" (1.5cm).
- 2. REFER TO TPO DETAIL U-5B FOR FLASHING VERTICAL JOINTS IN COATED METAL.

