



NOTES:

1. FASTENERS MUST PENETRATE INTO WOOD OR METAL STUDS, WHERE WALL IS BUILT WITH STUDS.
2. HP-X FASTENERS AND RhinoBOND PLATES ARE REQUIRED OVER STEEL AND WOOD DECKS.

<div style="display: flex; align-items: center;"> <div style="width: 20px; height: 10px; background-color: blue; margin-right: 5px;"></div> <div>→ THERMOPLASTIC MEMBRANE</div> </div> <div style="display: flex; align-items: center;"> <div style="width: 20px; height: 10px; border: 1px solid black; background-image: linear-gradient(to right, black 1px, transparent 1px); background-size: 10px 10px; margin-right: 5px;"></div> <div>→ APPROVED SUBSTRATE</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid red; padding: 0 2px; margin-right: 5px;">0</div> <div>→ SEE NOTE(S)</div> </div>	<div style="text-align: center;">RhinoBond WALL ATTACHMENT</div> <div style="text-align: center; font-size: small;">For additional information, refer to Specifications</div>	<div style="text-align: center;">  </div>	<div style="text-align: center;">DETAIL NO.</div> <div style="text-align: center; font-size: large;">RB-3</div> <div style="text-align: center; font-weight: bold;">RhinoBond</div>
--	---	--	---