





ANGLE CHANGE SECUREMENT

NOTES:

- VersiWELD MEMBRANE REQUIRES VersiWELD BONDING ADHESIVE AND VersiFLEX MEMBRANE REQUIRES VersiFLEX BONDING ADHESIVE.
- 2. HPVX FASTENERS AND RhinoBOND PLATES ARE REQUIRED OVER STEEL AND WOOD DECKS. FOR WARRANTY WIND SPEEDS GREATER THAN 72 MPH PLEASE CONTACT VERSICO FOR REQUIRED FASTENING ENHANCEMENTS



ANGLE CHANGE SECUREMENT METHOD WITH RhinoBond PLATES

VERSICO RhinoBond

RB-2