



- SEQUENCE:**
1. 3" (7.6cm) REINFORCED MEMBRANE STRIPPING.
 2. FIELD MEMBRANE.
 3. TOP 6" (15.2cm) NON- REINFORCED MEMBRANE STRIPPING.

NOTES:

1. PLACE A LAYER OF PVC MEMBRANE UNDER THE METAL CAP TO PROTECT AGAINST MOISTURE INFILTRATION AT JOINTS.
2. FASTEN COATED METAL FLASHING TO WOOD NAILERS USING 1- 1/2" (4cm) MIN. RING SHANK NAILS SPACED 6" (15cm) ON CENTER AND STAGGERED APPROX. 1/2" (1.5cm).

HEAT WELD 3" (7.5cm) WIDE PIECE OF REINFORCED MEMBRANE CENTRALLY ALIGNED OVER JOINT

HEAT WELD 6" (15cm) WIDE PIECE OF NON-REINFORCED MEMBRANE CENTRALLY ALIGNED OVER JOINT, COVERING TOP OF FIELD MEMBRANE. SEE SEQUENCE IN TABLE.



PVC COATED METAL WALL FLASHING
 MAXIMUM WARRANTY: 30 YEARS

DETAIL NO.
U- 12C
 U (Universal Detail)