



VersiFlex™ & VersiFleece® KEE HP PVC Roof Families


KEE HP
FULLY ADHERED



VersiFlex™
KEE HP




KEE HP
MECHANICALLY
FASTENED



VersiFlex™
KEE HP




KEE HP
INDUCTION
WELDED




VersiFlex™
KEE HP




Fleece
KEE HP




VersiFleece®
KEE HP




KEE HP
VEGETATED ROOF
TRADITIONAL




Traditional Roof Garden
With VersiFlex™
KEE HP PVC Membrane




FLEECE KEE HP
VEGETATED ROOF
TRADITIONAL



Traditional Roof Garden
With VersiFleece®
KEE HP PVC Membrane



Standard Colors



Revit Model Families Notes

General

The Revit model families provided contain multiple product selections for:

- Membranes
- Membrane Bonding Adhesives
- Coverboards
- Insulations
- Growth Media Depths (Roof Garden Assemblies Only)



Please select only one product for each of these layers to use and remove/delete the other products. This allows the customization of your roof assembly to meet your product selections.

Choosing a Versico Roof Assembly Family for your project

1. Navigate to the Roof Assembly which you would like to use.
2. Click on the Family or square shown above the Isometric of the roof assembly.
3. Copy the family to your clipboard by selecting Ctrl + C on your keyboard.
4. Navigate to your project file you wish to import the family.
5. Paste the family from your clipboard by selecting Ctrl + V on your keyboard.
6. When creating a new roof, choose the Versico Roof Assembly from your choices of Roof Families.

Editing the Family by Product Selection

1. Select the Family you wish to use, Adhered Assembly, Mechanically Fastened, etc.
2. Import the Versico Roof Assembly Family into your project.
3. In your project file, select the Versico Roof Assembly Family and double click, this opens the Family Property Box.
4. Open the Edit Construction tab within the Type Parameters Box.
5. Select the membrane(s) you are not using for your project from the list and click on it.
6. This highlights the selection. Click on Delete from the action buttons at the bottom of the list.
7. NOTE: This action will need to be repeated for each membrane deletion.
8. Repeat Step 5-7 for Membrane Bonding Adhesive, Coverboards, Insulations and Growth Media Depth, if using a Roof Garden Assembly Family.




InsulFoil EPS Insulation Roof Family

Material Selection Notes:

1. InsulFoil EPS is not compatible with solvent-based adhesives. If solvent based adhesives are to be used, a coverboard must separate the membrane adhesive from the EPS insulation.
2. Flexible DASH™ (Low-Rise Polyurethane) Adhesive is compatible for direct attachment in Fully adhered systems between:
 - A. VapAir Seal MD/ 725TR air and vapor barrier (where used) and lower insulation layer
 - B. Structural Deck and lower insulation layers where air/vapor barrier is not utilized
 - C. EPS Insulation layers
 - D. Coverboards and insulation
 - E. VersiFleece® membranes (excluding VersiFleece® RL™ membranes) and coverboards/EPS insulation.
3. Coverboards must be used where InsulFoil EPS is the primary insulating roof board and Induction Welding is the membrane attachment method.

Traditional Roof Garden Families Selection Notes:

1. Edit Core Boundary Roof Components as directed above.



2. Once growth media depth has been determined, delete extraneous growth media layers.

