



## SEQUENCE:

1. REINFORCED MEMBRANE STRIPPING.
2. FIELD MEMBRANE.
3. TOP UN-REINFORCED MEMBRANE STRIPPING.

DIMENSIONS	cm	
(A) 1"	2.5	MIN.
(B) 2.5"	5	MIN.

1. TEMPERATURE OF PENETRATIONS MUST NOT EXCEED 160° F (71° C).
2. TPO PRIMER MUST BE APPLIED TO ALL INSIDE SURFACES AND PENETRATIONS PRIOR TO FILLING WITH SEALANT..
3. FILL POCKET COMPLETELY WITH WHITE ONE-PART POURABLE SEALER UNTIL RIM IS COVERED WITH SEALANT; ENSURE ALL VOIDS ARE FILLED.
4. ON MECHANICALLY-ATTACHED SYSTEMS, INSTALL A MINIMUM OF 4 FASTENING PLATES AROUND SEALANT POCKETS WITH A DIAMETER UP TO 6" (152mm). ADDITIONAL FASTENING PLATES WILL BE REQUIRED FOR SEALANT POCKETS GREATER THAN 6" IN DIAMETER AND SHALL BE SPACED 12" (305mm) ON CENTER MAXIMUM. FASTENERS/PLATES ARE NOT REQUIRED ON ADHERED SYSTEMS UNLESS SEALANT POCKET DIAMETER EXCEEDS 18" (305mm).
5. REFER TO VERSICO SPECIFICATIONS FOR PROPER TYPES OF FASTENERS AND PLATES.
6. SECUREMENT IS REQUIRED FOR POURABLE SEALER POCKETS WHICH ARE GREATER THAN 18" (46 CM) IN DIAMETER. REFER TO SPECIFICATIONS.
7. WHEN ANY ONE SIDE OF THE FIELD FABRICATED, POURABLE SEALER POCKET EXCEEDS 12" (30 CM), USE WOOD BLOCKING TO ANCHOR SHEET METAL.

