







NOTE: SureTite Drip Edge ASSEMBLY CAN BE USED, BOTH ON ROOF EDGE AND PARAPET WALL.



FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)										22 GA (0.030")		0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95			
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8




DRIP EDGE 	SureTite Drip Edge Cleat CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.	ANSI/SPRI/ES-1 TESTED WIND RESISTANCE	METAL EDGING ME 1.1	
		APPLICABLE PRESSURES LBS./SQ.FT.		
		HORIZONTAL		168
		VERTICAL		




FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)													22 GA (0.030")		0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

DRIP EDGE 	3" SureTite Drip Edge	ANSI/SPRI/ES-1 TESTED WIND RESISTANCE APPLICABLE PRESSURES LBS./SQ.FT. HORIZONTAL VERTICAL	METAL EDGING ME 1.2
	CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.	FOR ADDITIONAL INFORMATION, REFER TO SPECS.	168
			168
			168






DIMENSIONS IN TO IN



FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)													22 GA (0.030")		0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8




DRIP EDGE 	5" SureTite Drip Edge	ANSI/SPRI/ES-1 TESTED WIND RESISTANCE APPLICABLE PRESSURES LBS./SQ.FT. HORIZONTAL VERTICAL	METAL EDGING ME 1.3	
	CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.			FOR ADDITIONAL INFORMATION, REFER TO SPECS.




FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)													22 GA (0.030")		0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

DRIP EDGE 	6" SureTite Drip Edge	ANSI/SPRI/ES-1 TESTED WIND RESISTANCE	METAL EDGING ME 1.4	
	CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.			APPLICABLE PRESSURES LBS./SQ.FT.
		HORIZONTAL		168
		VERTICAL		168
FOR ADDITIONAL INFORMATION, REFER TO SPECS.				





DIMENSIONS IN TO IN



FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)													22 GA (0.030")		0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

DRIP EDGE 	7" SureTite Drip Edge	ANSI/SPRI/ES-1 TESTED WIND RESISTANCE APPLICABLE PRESSURES LBS./SQ.FT. HORIZONTAL 168 VERTICAL	METAL EDGING	
	CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.		FOR ADDITIONAL INFORMATION, REFER TO SPECS.	ME 1.5



STEP 1

INSTALL DRIP EDGE MITERS FIRST. INSERT ONE SPLICE PLATE UNDER EACH END OF MITER WITH HIGH GRADE ARCHITECTURAL SEALANT TO BE FIELD APPLIED TO TOP OF EACH SPLICE AS SHOWN. FASTEN WITH NAILS.

STEP 2

POSITION 12'-0" CONTINUOUS CLEAT SECTIONS UNDER SPLICE PLATE AND MITER THEN FASTEN 12" O.C. AS SHOWN WITH 1-1/2" RING SHANK NAILS. LAP CONTINUOUS CLEAT 1" AT JOINTS.

STEP 3

INSERT ONE SPLICE PLATE UNDER LEFT END OF 12'-0" DRIP EDGE SECTION WITH SEALANT TO BE FIELD APPLIED TO TOP OF EACH SPLICE PLATE AS SHOWN.

STEP 4


INSTALL 12'-0" DRIP EDGE SECTIONS. HOOK DRIP EDGE OF EACH DRIP EDGE SECTION ONTO CONTINUOUS CLEAT, ROTATE INTO PLACE, AND FASTEN 6" O.C. WITH 1-1/2" RING SHANK NAILS. CONTINUE BY INSTALLING DRIP EDGE SECTIONS ALLOWING A 3/8" SPACE BETWEEN SECTIONS AS SHOWN, FIELD CUT AS NECESSARY.

CAUTION: REMOVE PROTECTIVE FILM IMMEDIATELY AFTER INSTALLATION. INSTALLERS SHALL WEAR PROTECTIVE EYEWEAR TO PREVENT INJURY.

FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)													22 GA (0.030")		0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

<p>DRIP EDGE</p>	<p>SureTite Drip Edge System With Continuous Cleat. Installation Instructions</p>		<p>ANSI/SPRI/ES-1</p> <p>TESTED WIND RESISTANCE</p>		<p>METAL EDGING</p> <p>ME 1.6</p>
	<p>CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.</p>		<p>APPLICABLE PRESSURES LBS./SQ.FT.</p>		
	<p>FOR ADDITIONAL INFORMATION, REFER TO SPECS.</p>		<p>HORIZONTAL</p> <p>168</p>		
			<p>VERTICAL</p>		



- 4-3/4"
- 6-1/4"
- 7-3/4"


SYMBOL

#10 x 1-1/2" STAINLESS STEEL FASTENERS.

1/2" (slot width)

5/32" (hole diameter)


SLOTTED PRE-PUNCHED HOLE






FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)										22 GA (0.030")													
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

FASCIA 	SureTite Fascia Cleat	ANSI/SPRI/ES-1 TESTED WIND RESISTANCE APPLICABLE PRESSURES LBS./SQ.FT. HORIZONTAL 95 VERTICAL	METAL EDGING ME 2.1
	CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.	FOR ADDITIONAL INFORMATION, REFER TO SPECS.	




SEE:
ME 2.1
 FOR CLEAT PROFILE &
 ADDITIONAL INFORMATION.
ME 2.6
 FOR INSTALLATION
 INSTRUCTIONS.






FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)											22 GA (0.030")		0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95		
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

FASCIA 	4-1/4" SureTite Fascia	ANSI/SPRI/ES-1 TESTED WIND RESISTANCE APPLICABLE PRESSURES LBS./SQ.FT. HORIZONTAL 95 VERTICAL	METAL EDGING	
	CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.		FOR ADDITIONAL INFORMATION, REFER TO SPECS.	ME 2.2




SEE:
[ME 2.1](#)
 FOR CLEAT PROFILE & ADDITIONAL INFORMATION.
[ME 2.6](#)
 FOR INSTALLATION INSTRUCTIONS.






FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)											22 GA (0.030")		0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95		
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

FASCIA 	5-1/4" SecurTite Fascia		ANSI/SPRI/ES-1 TESTED WIND RESISTANCE		METAL EDGING ME 2.3
	CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.		APPLICABLE PRESSURES LBS./SQ.FT.		
	FOR ADDITIONAL INFORMATION, REFER TO SPECS.		HORIZONTAL 95		
			VERTICAL		




SEE:
[ME 2.1](#)
 FOR CLEAT PROFILE &
 ADDITIONAL INFORMATION.
[ME 2.6](#)
 FOR INSTALLATION
 INSTRUCTIONS.



FOR WIND UPLIFT
 CALCULATIONS


CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)											22 GA (0.030")		0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95		
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

FASCIA 	6-1/4" SecurTite Fascia		ANSI/SPRI/ES-1 TESTED WIND RESISTANCE		METAL EDGING ME 2.4
			APPLICABLE PRESSURES LBS./SQ.FT.		
			HORIZONTAL 95		
			VERTICAL		
CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.		FOR ADDITIONAL INFORMATION, REFER TO SPECS.			




STEP 1
POSITION MEMBRANE OVER THE ROOF EDGE AND DOWN OUTSIDE FACE OF WALL, COVERING WOOD NAILER(S) COMPLETELY. ALLOW 1/2" EXCESS MEMBRANE.


IMPORTANT: OUTSIDE EDGE OF WOOD NAILER(S) (MINIMUM 2X4) SHALL BE ALIGNED FLUSH WITH OR EXTEND SLIGHTLY PAST OUTERMOST EDGE OF WALL.



STEP 2
MITER & SCUPPER BASE RAIL (PREPARATION): LAY MITERS AND SPILLOUT SCUPPERS ON DECK WITH OUTSIDE FACE DOWN. BE SURE ALUMINUM BASE RAIL IS CLEAN AND FREE OF DIRT OR DUST. APPLY A HEAVY 3/8" BEAD OF NON-CURING SEALANT TO THE RAIL DECK FLANGE AS SHOWN. APPLICATION OF SEALANT IS REQUIRED ALONG THE FULL LENGTH OF EACH MITER BASE RAIL. APPLY A SIMILAR 3/8" BEAD OF MASTIC TO THE FLANG'S LEFT END, AS YOU LOOK AT THE OUTSIDE FACE OF THE RAIL SECTION.



STEP 3
FOLD ROOFING MEMBRANE AT CORNERS AND LOOSELY FASTEN MITERS USING 2" HEX HEAD STAINLESS STEEL FASTENERS AND DRIVER BIT PROVIDED BY CARLISLE. NEXT LOCATE AND INSTALL SPILLOUTS AND SCUPPERS WITH SEALANT & 2" FASTENERS.





STEP 4
INSTALL 12'-0" SECTIONS OF BASE RAIL WITH MASTIC AS SHOWN IN STEP 2. INSTALL BASE RAIL RIGHT TO LEFT, (AS SEEN FROM ROOFTOP) LAPPING BASE RAIL JOINTS 1". FASTEN BAR TO WALL WITH PROVIDED FASTENERS.

FOR WIND UPLIFT CALCULATIONS



CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)										22 GA (0.030")													
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

<p>FASCIA</p>	<p>SureTite Fascia. Adhered & Mechanically Attached Membranes. Installation Instructions. Page 1 of 2</p>	<p>ANSI/SPRI/ES-1</p> <p>TESTED WIND RESISTANCE</p>	<p>METAL EDGING</p>
		<p>APPLICABLE PRESSURES LBS./SQ.FT.</p>	<p>ME 2.6</p>
	<p>HORIZONTAL</p>	<p>95</p>	
	<p>VERTICAL</p>	<p>FOR ADDITIONAL INFORMATION, REFER TO SPECS.</p>	<p>CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.</p>



STEP 5
FASCIA MITER COVERS:
 PLACE SPLICE PLATE INTO EACH END OF MITER COVER. SIMPLY POSITION THE COVER ATOP RAIL AND WITH PALM OF HAND APPLY SLIGHT PRESSURE DOWNWARD UNTIL ENGAGED TO BASE RAIL.

STEP 6
FASCIA COVERS:
 POSITION 12' FASCIA COVERS ON TOP OF BASE RAIL. FASCIA COVERS SHALL BE INSTALLED FROM LEFT TO RIGHT AS SEEN FROM ROOFTOP. PLACE SPLICE PLATE IN RIGHT END OF COVER. SNAP RIGHT COVER ONTO BASE RAIL BY APPLYING DOWNWARD PRESSURE WITH PALM OF THE HAND UNTIL FASCIA COVER IS FULLY ENGAGED ALONG THE ENTIRE LENGTH. FIELD CUT COVERS AS REQUIRED USING FINE TOOTH HACKSAW. NOTE: REMOVE PROTECTIVE FILM IMMEDIATELY.




STEP 7
 POSITION PRE-NOTCHED COVER AND SNAP ONTO BASE RAIL BY PRESSING DOWN WITH THE PALM OF YOUR HAND UNTIL THE COVER IS FULLY ENGAGED ALONG THE ENTIRE LENGTH. ALLOW 3/8" GAP BETWEEN COVER SECTIONS. FIELD CUT WHERE NECESSARY USING A FINE TOOTH HACKSAW.

STEP 8
 FIELD NOTCH RIGHT SIDE OF COVER AS SHOWN. SNAP ONTO BASE RAIL BY PRESSING DOWN WITH THE PALM OF YOUR HAND UNTIL THE COVER IS FULLY ENGAGED ALONG THE ENTIRE LENGTH. ALLOW 3/8" GAP BETWEEN COVER SECTIONS. FIELD CUT WHERE NECESSARY USING A FINE TOOL HACKSAW.

FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)												22 GA (0.030")											
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	3/8"	0.95
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

FASCIA 	SureTite Fascia. Adhered & Mechanically Attached Membranes. Installation Instructions. Page 2 of 2	ANSI/SPRI/ES-1 TESTED WIND RESISTANCE	METAL EDGING
	CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.	FOR ADDITIONAL INFORMATION, REFER TO SPECS.	APPLICABLE PRESSURES LBS./SQ.FT. HORIZONTAL: 95 VERTICAL:



TYPICAL INSTALLATION


FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)										22 GA (0.030")													
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

<p>FASCIA</p>	<p>SureTite Fascia (Fully Adhered & Mechanically Fastened Assemblies)</p>	<p>ANSI/SPRI/ES-1</p> <p>TESTED WIND RESISTANCE</p>	<p>METAL EDGING</p>
		<p>APPLICABLE PRESSURES LBS./SQ.FT.</p>	
	<p>HORIZONTAL</p>	<p>95</p>	
	<p>VERTICAL</p>		




CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.

FOR ADDITIONAL INFORMATION, REFER TO SPECS.



12" O.C.
(FOR 3", 5", 6" & 7" CLEATS)




SecurTite Drip Edge Cleat, 22 GA. (0.030") GALVANIZED CLEAT



FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)												22 GA (0.030")		0.076		1/32"		0.08		1/8"		0.32		5/32"		0.4		3/8"		0.95																																																																	
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18	1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10	4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57	7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

<p>FLAT COPING</p>	SecurTite Drip Edge Cleat		<p>ANSI/SPRI/ES-1</p> <p>TESTED WIND RESISTANCE</p>		METAL EDGING	
	CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.		FOR ADDITIONAL INFORMATION, REFER TO SPECS.		<p>APPLICABLE PRESSURES LBS./SQ.FT.</p>	
					<p>HORIZONTAL 66</p>	
					<p>VERTICAL 110</p>	
				ME 3.1		






NOTE:
SEE [ME 3.6](#) FOR 3D FABRICATION INSTRUCTIONS

FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)										22 GA (0.030")													
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

<p>FLAT COPING</p> <p>CARLISLE SYNTEC SYSTEMS</p>	<p>3" SecurTite Coping Flat Version</p> <p>CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.</p>	<p>FOR ADDITIONAL INFORMATION, REFER TO SPECS.</p>	<p>ANSI/SPRI/ES-1</p> <p>TESTED WIND RESISTANCE</p>	METAL EDGING	
			<p>APPLICABLE PRESSURES</p> <p>HORIZONTAL</p>	<p>LBS./SQ.FT.</p> <p>66</p>	<p>ME 3.2</p>
			<p>VERTICAL</p>	<p>110</p>	





NOTE:
SEE [ME 3.6](#) FOR 3D FABRICATION INSTRUCTIONS

FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)										22 GA (0.030")													
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

<p>FLAT COPING</p> <p></p>	<p>5" SecurTite Coping Flat Version</p> <p>CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.</p>	<p>FOR ADDITIONAL INFORMATION, REFER TO SPECS.</p>	<p>ANSI/SPRI/ES-1</p> <p>TESTED WIND RESISTANCE</p>	METAL EDGING	
			<p>APPLICABLE PRESSURES</p> <p>LBS./SQ.FT.</p>	<p>ME 3.3</p>	
			<p>HORIZONTAL</p>		<p>66</p>
			<p>VERTICAL</p>		<p>110</p>






NOTE:
SEE [ME 3.6](#) FOR 3D FABRICATION INSTRUCTIONS


FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)										22 GA (0.030")													
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

<p>FLAT COPING</p>	<p>6" SecurTite Coping Flat Version</p>	<p>ANSI/SPRI/ES-1</p> <p>TESTED WIND RESISTANCE</p>	METAL EDGING	
		<p>APPLICABLE PRESSURES LBS./SQ.FT.</p>	<p>ME 3.4</p>	
		<p>HORIZONTAL</p>		<p>66</p>
		<p>VERTICAL</p>		<p>110</p>
<p>CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.</p>		<p>FOR ADDITIONAL INFORMATION, REFER TO SPECS.</p>		



NOTE:
SEE [ME 3.6](#) FOR 3D
FABRICATION INSTRUCTIONS



FOR WIND UPLIFT
CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)													22 GA. (0.030")																			
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18	0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57

FLAT COPING 	7" SecurTite coping Flat Version	ANSI/SPRI/ES-1 TESTED WIND RESISTANCE APPLICABLE PRESSURES LBS./SQ.FT. HORIZONTAL 66 VERTICAL 110	METAL EDGING ME 3.5
	CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.	FOR ADDITIONAL INFORMATION, REFER TO SPECS.	

IMPORTANT

PRIOR TO INSTALLATION, READ INSTRUCTIONS CAREFULLY.


NOTE:

POSITION ROOF MEMBRANE ON TOP OF THE WALL, COVERING THE WOOD NAILER(S) OR SUBSTRATE COMPLETELY. ALLOW 1/2" MINIMUM EXCESS MEMBRANE BEYOND NAILER WHERE APPLICABLE. MEMBRANE NOT SHOWN FOR CLARITY.

CAUTION:

INSTALL MITERS FIRST

NOTE: FASTENERS TO MEET MINIMUM OF 240 POUNDS PULL-OUT FORCE FOR SUBSTRATE




STEP 1 CONTINUOUS CLEAT

PLACE A 12'-0" LENGTH OF CONTINUOUS CLEAT ON THE OUTSIDE FACE ALONG THE WALL. FASTEN CLEAT INTO SUBSTRATE THRU FACE OF CLEAT WITH PROVIDED NAILS AT 12" O.C.


STEP 2 MITER SPLICE PLATES:

FIELD APPLY SEALANT TO TOP OF EACH SPLICE PLATE AS SHOWN. INSTALL THE SPLICE PLATE HALFWAY INTO EACH END OF THE MITER AS SHOWN.




STEP 3 MITER ASSEMBLY

HOOK OUTSIDE FACE OF MITER ASSEMBLY ONTO BOTTOM OF CONTINUOUS CLEAT AND ROTATE INTO PLACE AS SHOWN.



STEP 4 CONTINUOUS CLEAT

SLIDE SECOND 12'-0" SECTION OF CONTINUOUS CLEAT UNDER THE OTHER LEG OF MITER COVER INSURING THAT THE DRIP OF THE CLEAT IS ENGAGED TO THAT OF THE COVER. FASTEN CLEAT AS IN STEP ONE. DRILL AND FASTEN THROUGH INSIDE FACE OF COVER TO NAILER WITH PROVIDED SCREW.



6" WIDE SPLICE PLATE AT JOINTS

COPING COVER 12' LENGTH)

USE SHEET METAL (DUCK-BILLED) PLIERS ONLY

#10 X 1-1/2" STAINLESS STEEL FASTENERS PROVIDED. CENTER FASTENERS IN NAILER @ 24" O.C. (PROVIDED)

1-1/2" RING SHANK NAILS CENTERED IN NAILER @ 12" O.C.

22 GA. GALVANIZED CONTINUOUS CLEAT

FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)											22 GA (0.030")												
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

FLAT COPING

SecurTite Coping Flat Version. Installation Instructions. Page 1 of 2

ANSI/SPRI/ES-1

TESTED WIND RESISTANCE	
APPLICABLE PRESSURES	LBS./SQ.FT.
HORIZONTAL	66
VERTICAL	110


METAL EDGING

ME 3.6

CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.

FOR ADDITIONAL INFORMATION, REFER TO SPECS.






STEP 6 ENDCAPS:

LOCATE AND ATTACH CLEAT AS IN STEP 1. FIELD APPLY SEALANT TO TOP OF EACH SPLICE PLATE AS SHOWN. INSTALL THE SPLICE PLATE ASSEMBLY HALFWAY INTO END OF THE ENDCAP AS SHOWN.

RIGHT HAND ENDCAP SHOWN




STEP 6 ENDCAPS (CONT.)

HOOK OUTSIDE FACE OF ENDCAP ONTO THE CONTINUOUS CLEAT AND ROTATE INTO PLACE. FASTEN INSIDE FACE WITH PROVIDED SCREW.

STEP 7 - CONTINUOUS CLEAT:

POSITION 12'-0" CONTINUOUS CLEAT SECTIONS THEN FASTEN 12" O.C. AS SHOWN WITH PROVIDED NAILS. LAP CLEAT 1" AT JOINTS. INSERT ONE SPLICE PLATE UNDER END OF 12'-0" COPING SECTION WITH SEALANT, TO BE FIELD APPLIED TO TOP OF EACH SPLICE PLATE AS SHOWN. ROTATE COPING INTO PLACE.




STEP 8 - COPING

INSTALL 12'-0" COPING SECTIONS. HOOK DRIP EDGE OF EACH COPING SECTION ONTO CONTINUOUS CLEAT, ROTATE INTO PLACE.

STEP 9 - COMPLETION

LEAVE A 3/8" GAP BETWEEN COVER SECTIONS TO ALLOW FOR THERMAL EXPANSION. FASTEN INSIDE FACE OF COVER WITH PROVIDED SCREWS 12" FROM EDGE AND 24" O.C. DOWN LENGTH OF COPING COVER. FIELD CUT WHERE NECESSARY USING A FINE TOOTH HACKSAW OR SNIPS.



CAUTION:

REMOVE PROTECTIVE FILM IMMEDIATELY AFTER INSTALLATION. INSTALLERS SHALL WEAR PROTECTIVE EYEWEAR TO PREVENT EYE INJURY

FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)													22 GA (0.030")										
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	1/8"	0.32	5/32"	0.4	3/8"	0.95
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

FLAT COPING

SecurTite Coping Flat Version. Installation Instructions. Page 2 of 2

ANSI/SPRI/ES-1

TESTED WIND RESISTANCE	
APPLICABLE PRESSURES	LBS./SQ.FT.
HORIZONTAL	66
VERTICAL	110






METAL EDGING

ME 3.6

CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.

FOR ADDITIONAL INFORMATION, REFER TO SPECS.





FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)										22 GA (0.030")		0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95			
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8




GRAVEL STOP SureTite Gravel Stop Edge System – Continuous Cleat & Splice Plate

CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.

FOR ADDITIONAL INFORMATION, REFER TO SPECS.



ANSI/SPRI/ES-1	
TESTED WIND RESISTANCE	
APPLICABLE PRESSURES	LBS./SQ.FT.
HORIZONTAL	106
VERTICAL	

METAL EDGING
ME 4.1



NOTES:

- SEE [ME 4.1](#) FOR CLEAT & SPLICE PLATE ADDITIONAL INFORMATION.
- SEE [ME 4.6](#) FOR 3D INSTALLATION INSTRUCTIONS.



FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)											22 GA (0.030")												
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

GRAVEL STOP

4" SureTite Gravel Stop

ANSI/SPRI/ES-1

TESTED WIND RESISTANCE	
APPLICABLE PRESSURES	LBS./SQ.FT.
HORIZONTAL	106
VERTICAL	


METAL EDGING

ME 4.2

CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.




FOR ADDITIONAL INFORMATION, REFER TO SPECS.





NOTES:

- SEE [ME 4.1](#) FOR CLEAT & SPLICE PLATE ADDITIONAL INFORMATION.
- SEE [ME 4.6](#) FOR 3D INSTALLATION INSTRUCTIONS.



FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)												22 GA (0.030")											
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

GRAVEL STOP

SYNTEC SYSTEMS

6" SureTite Gravel Stop

CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.

FOR ADDITIONAL INFORMATION, REFER TO SPECS.

ANSI/SPRI/ES-1

TESTED WIND RESISTANCE

APPLICABLE PRESSURES LBS./SQ.FT.


HORIZONTAL

106

VERTICAL




METAL EDGING

ME 4.3



NOTES:

1. SEE ME 4.1 FOR CLEAT & SPLICE PLATE ADDITIONAL INFORMATION.
2. SEE ME 4.6 FOR 3D INSTALLATION INSTRUCTIONS.



FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)													22 GA (0.030")		0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

GRAVEL STOP

7" SureTite Gravel Stop

ANSI/SPRI/ES-1

TESTED WIND RESISTANCE	
APPLICABLE PRESSURES	LBS./SQ.FT.
HORIZONTAL	106
VERTICAL	


METAL EDGING

ME 4.4

CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.



FOR ADDITIONAL INFORMATION, REFER TO SPECS.





NOTES:

- SEE ME 4.1 FOR CLEAT & SPLICE PLATE ADDITIONAL INFORMATION.
- SEE ME 4.6 FOR 3D INSTALLATION INSTRUCTIONS.



FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)											22 GA (0.030")												
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

GRAVEL STOP


8" SureTite Gravel Stop

CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.

FOR ADDITIONAL INFORMATION, REFER TO SPECS.

ANSI/SPRI/ES-1	
TESTED WIND RESISTANCE	
APPLICABLE PRESSURES	LBS./SQ.FT.
HORIZONTAL	106
VERTICAL	

METAL EDGING
ME 4.5




STEP 1
 INSTALL DRIP EDGE MITERS FIRST. INSERT ONE SPLICE PLATE UNDER EACH END OF MITER WITH HIGH GRADE ARCHITECTURAL SEALANT TO BE FIELD APPLIED TO TOP OF EACH SPLICE AS SHOWN. FASTEN WITH NAILS.

STEP 2
 POSITION 12'-0" CONTINUOUS CLEAT SECTIONS UNDER SPLICE PLATE AND MITER THEN FASTEN 12" O.C. AS SHOWN WITH 1-1/2" RING SHANK NAILS. LAP CONTINUOUS CLEAT 1" AT JOINTS.

STEP 3
 INSERT ONE SPLICE PLATE UNDER LEFT END OF 12'-0" DRIP EDGE SECTION WITH SEALANT TO BE FIELD APPLIED TO TOP OF EACH SPLICE PLATE AS SHOWN.

STEP 4
 INSTALL 12'-0" DRIP EDGE SECTIONS. HOOK DRIP EDGE OF EACH DRIP EDGE SECTION ONTO CONTINUOUS CLEAT, ROTATE INTO PLACE, AND FASTEN 6" O.C. 1-1/2" RING SHANK NAILS. CONTINUE BY INSTALLING DRIP EDGE SECTIONS ALLOWING A 3/8" SPACE BETWEEN SECTIONS AS SHOWN, FIELD CUT AS NECESSARY.

CAUTION: REMOVE PROTECTIVE FILM IMMEDIATELY AFTER INSTALLATION. INSTALLERS SHALL WEAR PROTECTIVE EYEWEAR TO PREVENT INJURY.



FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)													22 GA (0.030")		0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8





SureTite Gravel Stop Edge System – Continuous Cleat Version – 3D View

CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.


FOR ADDITIONAL INFORMATION, REFER TO SPECS.

ANSI/SPRI/ES-1	
TESTED WIND RESISTANCE	
APPLICABLE PRESSURES	LBS./SQ.FT.
HORIZONTAL	106
VERTICAL	

METAL EDGING
ME 4.6






NOTE:
 SureTite Drip Edge Cleat CAN BE USED FOR:
 SureTite Fascia SYSTEM &
 SureTite Tapered Coping SYSTEM.



FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)													22 GA (0.030")		0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

TAPERED COPING 	SureTite Drip Edge Cleat		ANSI/SPRI/ES-1 TESTED WIND RESISTANCE		METAL EDGING ME 5.1
	CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.		APPLICABLE PRESSURES LBS./SQ.FT.		
	FOR ADDITIONAL INFORMATION, REFER TO SPECS.		HORIZONTAL 67		
			VERTICAL 107		






BEND ANGLES		
"A"	(X)	(Y)
12"	86°	96°
11"/12"	85°	97°
9"	84°	98°
8"	83°	99°
7"	82°	100°
6"	81°	101°
5"	79°	103°

FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)												22 GA (0.030")				FOR WIND UPLIFT CALCULATIONS							
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

<p>TAPERED COPING</p>	4-1/4" SureTite Tapered Coping	<p>ANSI/SPRI/ES-1</p> <p>TESTED WIND RESISTANCE</p> <p>APPLICABLE PRESSURES LBS./SQ.FT.</p> <p>HORIZONTAL 67</p> <p>VERTICAL 107</p>	METAL EDGING	
	CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.		FOR ADDITIONAL INFORMATION, REFER TO SPECS.	ME 5.2






BEND ANGLES		
"A"	(X)	(Y)
12"	86°	96°
11"/12"	85°	97°
9"	84°	98°
8"	83°	99°
7"	82°	100°
6"	81°	101°
5"	79°	103°

FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)														22 GA (0.030")																		
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18	0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10	
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57	
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8	

<p>TAPERED COPING</p>	5-1/4" SureTite Tapered Coping		<p>ANSI/SPRI/ES-1</p> <p>TESTED WIND RESISTANCE</p>		<p>METAL EDGING</p> <p>ME 5.3</p>
	CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.		FOR ADDITIONAL INFORMATION, REFER TO SPECS.		
			APPLICABLE PRESSURES LBS./SQ.FT.		
			HORIZONTAL 67		
				VERTICAL 107	




BEND ANGLES		
"A"	(X)	(Y)
12"	86°	96°
11"/12"	85°	97°
9"	84°	98°
8"	83°	99°
7"	82°	100°
6"	81°	101°
5"	79°	103°

FOR WIND UPLIFT CALCULATIONS



CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)												22 GA (0.030")																				
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18	0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10	
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57	
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8	

TAPERED COPING 	6-1/4" SureTite Tapered Coping	ANSI/SPRI/ES-1 TESTED WIND RESISTANCE	METAL EDGING		
	CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.		FOR ADDITIONAL INFORMATION, REFER TO SPECS.	APPLICABLE PRESSURES LBS./SQ.FT.	
		HORIZONTAL		67	ME 5.4
		VERTICAL		107	



OUTSIDE FACE
8-1/4"

INSIDE FACE
B 3" MAX.



BEND ANGLES		
"A"	(X)	(Y)
12"	86°	96°
11"/12"	85°	97°
9"	84°	98°
8"	83°	99°
7"	82°	100°
6"	81°	101°
5"	79°	103°

FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)													22 GA (0.030")										
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

<p>TAPERED COPING</p>	8-1/4" SureTite Tapered Coping	<p>ANSI/SPRI/ES-1</p> <p>TESTED WIND RESISTANCE</p>	<p>METAL EDGING</p> <p>ME 5.5</p>
	<p>CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.</p>	<p>APPLICABLE PRESSURES LBS./SQ.FT.</p>	
	<p>FOR ADDITIONAL INFORMATION, REFER TO SPECS.</p>	<p>HORIZONTAL 67</p>	
		<p>VERTICAL 107</p>	


202501

<https://www.metalica.com/resources/calculators/wind>


IMPORTANT:
PRIOR TO INSTALLATION, READ INSTRUCTIONS CAREFULLY.

NOTE:
ENSURE THAT CARLISLE FLASHING MEMBRANE IS APPLIED OVER THE PARAPET AND NAILER IN ACCORDANCE WITH CARLISLE STANDARD SPECIFICATIONS AND DETAILS.


CAUTION:
INSTALL MITER FIRST.




STEP 1: CONTINUOUS CLEATS AT CORNERS
PLACE OUTSIDE CONTINUOUS CLEATS ON BOTH SIDES OF CORNER AND TWO INSIDE CONTINUOUS CLEATS ON BOTH SIDES. DO NOT FASTEN CLEATS AT THIS TIME.




STEP 2: CONTINUOUS CLEATS AT CORNERS
USING A SPLICE PLATE AS A SPACER, FASTEN INSIDE CONTINUOUS CLEAT TO WALL AT 12" O.C. USING PROVIDED FASTENERS. FOR FASTENER LOCATION, SEE [ME 5.1](#)




STEP 3: CONTINUOUS CLEATS AT CORNERS
FASTEN ONE OUTSIDE CONTINUOUS CLEAT AT 12" O.C. WITH PROVIDED FASTENERS. SEE [ME 5.1](#).



STEP 4: MITER SPLICE PLATES
REMOVE RELEASE PAPER FROM SPLICE PLATE SEALANT STRIPS. INSTALL THE SPLICE PLATES INTO EACH END OF THE MITER AS SHOWN.




STEP 5: MITER
HOOK OUTSIDE FACE OF MITER ASSEMBLY ONTO CONTINUOUS CLEAT AND ROTATE INTO PLACE.



STEP 6: CONTINUOUS CLEAT
INSTALL FOURTH CONTINUOUS CLEAT BY SLIDING IT UNDER THE MITER, BEING SURE TO ENGAGE DRIPS. FASTEN TO THE WALL 12" O.C. WITH PROVIDED FASTENERS. FIELD CRIMP DRIP ON INSIDE FACE ([SEE CRIMP DETAIL, STEP 9](#))

FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)										22 GA (0.030")													
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8



SureTite Tapered Version – Installation instructions. Page 1 of 2


CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.

FOR ADDITIONAL INFORMATION, REFER TO SPECS.


ANSI/SPRI/ES-1	
TESTED WIND RESISTANCE	
APPLICABLE PRESSURES	LBS./SQ.FT.
HORIZONTAL	67
VERTICAL	107

METAL EDGING
ME 5.6

202501





STEP 7 – CONTINUOUS CLEATS
 USING A SPLICE PLATE AS A SPACER AS SHOWN IN [STEP 2](#), LOCATE CONTINUOUS CLEATS ALONG INSIDE AND OUTSIDE WALL AND FASTEN BOTH CLEATS @ 12" O.C. WITH PROVIDED FASTENERS. LEAVE A 1/4" GAP BETWEEN CONTINUOUS CLEATS AS SHOWN ABOVE.



STEP 8 – ENDCAPS
 REMOVE RELEASE PAPER FROM SPLICE PLATE SEALANT STRIPS. PLACE SPLICE PLATE HALFWAY INTO ENDCAP. HOOK OUTSIDE FACE OF ENDCAP ONTO THE CONTINUOUS CLEAT AND ROTATE INTO PLACE. FIELD CRIMP DRIP ON INSIDE FACE ([SEE CRIMP DETAIL, STEP 9](#))

INSTALLATION NOTES:

1. INSTALLER SHALL CHECK AS-BUILT CONDITIONS, INCLUDING NAILER ATTACHMENT AND VERIFY THE CARLISLE COPING DETAILS FOR ACCURACY TO FIT THE WALL ASSEMBLY PRIOR TO FABRICATION.
2. FASTENERS MUST BE CORROSION RESISTANT AND RATED FOR A MINIMUM 250 POUNDS PULLOUT FORCE FOR THE SUBSTRATE THAT IS BEING USED.



STEP 9 – COPING SECTIONS
 REMOVE RELEASE PAPER FROM SPLICE PLATE SEALANT STRIPS AND PLACE INTO END OF 12'-0" COPING SECTION AS SHOWN. HOOK DRIP EDGE OF EACH COPING SECTION ONTO CONTINUOUS CLEAT, ROTATE INTO PLACE. FIELD CRIMP DRIP ON INSIDE FACE AT SPLICE JOINT AND 18" O.C.
 NOTE: REMOVE PROTECTIVE FILM IMMEDIATELY.

FOR WIND UPLIFT CALCULATIONS

CONVERSION TABLE: INCHES & FEET TO CENTIMETERS (SMALLEST TO LARGEST DIMENSIONS IN ORDER)												22 GA (0.030")																											
7/16"	1.11	15/32"	1.19	1/2"	1.27	5/8"	1.59	21/32"	1.67	11/16"	1.75	13/16"	2.06	7/8"	2.22	15/16"	2.38	31/32"	2.46	1-3/16"	3.02	1-1/4"	3.18	0.076	1/32"	0.08	1/8"	0.32	5/32"	0.4	3/8"	0.95							
1-7/16"	3.65	1-1/2"	3.81	1-17/32"	3.89	2-1/8"	5.4	2-1/4"	5.72	2-15/32"	6.27	2-1/2"	6.35	2-15/16"	7.46	2-31/32"	7.54	3"	7.62	3-3/8"	8.57	3-15/16"	10	15/16"	2.38	1-3/16"	2.46	3"	7.62	3-3/8"	8.57	3-15/16"	10						
4"	10.16	4-1/4"	10.08	4-5/16"	10.95	4-3/8"	11.11	5"	12.7	5-1/4"	13.34	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57	5-5/16"	13.49	5-3/8"	13.65	5-7/8"	14.92	6"	15.24	6-1/4"	15.88	7-5/16"	18.57				
7-3/8"	18.73	7-7/8"	20	8"	20.32	8-1/4"	20.96	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8	8-5/16"	21.11	8-3/8"	21.27	9"	22.86	11"	27.94	12"	30.48	24"	60.96	10 FEET	304.8	12 FEET	365.8

TAPERED COPING



SureTite Tapered Version – Installation instructions. Page 2 of 2

CAUTION: ARCHITECT AND OR CONTRACTOR SHALL VERIFY ALL DIMENSIONS, SIZES AND QUANTITIES.

FOR ADDITIONAL INFORMATION, REFER TO SPECS.

ANSI/SPRI/ES-1

TESTED WIND RESISTANCE	
APPLICABLE PRESSURES	LBS./SQ.FT.
HORIZONTAL	67
VERTICAL	107

METAL EDGING

ME 5.6