



- 1. TEMPERATURE OF PENETRATIONS MUST NOT EXCEED 140° F (60° C).
- PRIMER MUST BE APPLIED TO ALL INSIDE SURFACES AND PENETRATIONS PRIOR TO FILLING WITH SEALANT..
- 3. FILL POCKET COMPLETELY WITH WHITE ONE—PART POURABLE SEALER UNTIL RIM IS COVERED WITH SEALANT; ENSURE ALL VOIDS ARE FILLED.
- 4. ON MECHANICALLY—ATTACHED SYSTEMS, INSTALL A MINIMUM OF 4 FASTENING PLATES AROUND SEALANT POCKETS WITH A DIAMETER UP TO 6" (152mm). ADDITIONAL FASTENING PLATES WILL BE REQUIRED FOR SEALANT POCKETS GREATER THAN 6" IN DIAMETER AND SHALL BE SPACED 12" (305mm) ON CENTER MAXIMUM. FASTENERS/PLATES ARE NOT REQUIRED ON ADHERED SYSTEMS UNLESS SEALANT POCKET DIAMETER EXCEEDS 18" (305mm).
- 5. REFER TO CARLISLE SPECIFICATIONS FOR PROPER TYPES OF FASTENERS AND PLATES.
- 6. SECUREMENT IS REQUIRED FOR POURABLE SEALER POCKETS WHICH ARE GREATER THAN 18" (46 CM) IN DIAMETER. REFER TO SPECIFICATIONS.
- 7. WHEN ANY ONE SIDE OF THE FIELD FABRICATED POURABLE SEALER POCKET EXCEEDS 12" (30 CM) USE WOOD BLOCKING TO ANCHOR SHEET METAL.







FIELD FABRICATED PVC COATED METAL POCKET



DETAIL NO.

U-16E

U (Universal Detail)