

- 1. REMOVE ALL GRAVEL AT TIE-IN.
- 2. SPLICE TWO PIECES OF ELASTOFORM OR PRESSURE—SENSITIVE ELASTOFORM TOGETHER TO ACHIEVE DESIRED WIDTH.
- 3. WATER CUT-OFF MUST BE UNDER CONSTANT COMPRESSION.
- 4. CARLISLE IS NOT RESPONSIBLE FOR DAMAGE TO THE BUILT-UP ROOF OR STRUCTURAL DECK RESULTING FROM PONDED WATER; THIS DETAIL APPLIES TO RE-ROOFING WHEN A TEAR-OFF IS NOT SPECIFIED AND WAS DESIGNED TO PREVENT MIGRATION OF WATER INTO THE NEW ROOFING SYSTEM.
- 5. ON BALLASTED SYSTEMS, USE CONCRETE PAVERS TO PREVENT BALLAST MIGRATION.

