

## NOTES:

1. REFER TO TABLES ON SHEETS ATTACHMENT 1-2 FOR DETAILED INSPECTION, CLEANING AND PRIMING FOR DIFFERENT MATERIALS WITHIN THE FLASHING AREAS.
2. IF FLUTES ARE PERPENDICULAR DRILL A 3/8" (1cm) WEEP HOLE IN THE BOTTOM FLUTES OF THE STEEL DECK ALONG THE TIE IN.
3. DETAIL NOT FOR USE ON WARRANTY PROJECTS EXCEEDING 20-YEARS. UNLESS OTHERWISE SPECIFIED.


<p>0 SEE NOTE(S)</p>	<p>TPO OR PVC MEMBRANE TIE-IN WITH EXISTING ROOF OVER STEEL DECK (PAGE 1 OF 2)</p> <p>For additional information, refer to Specifications</p>	<p>DETAIL NO.</p> <p>LF-13.2</p> <p>LIQUID FLASHING</p>
----------------------	---	---



INSTALL COATED SHEET METAL STRIPS WITH THREADED FASTENERS. REFER TO TABLES ON SHEETS [ATTACHMENT 1-2](#) FOR DETAILED INSPECTION, CLEANING AND PRIMING FOR DIFFERENT MATERIALS WITHIN THE FLASHING AREAS.



PROPERLY CLEAN WITH MEMBRANE CLEANER PRIOR TO WELDING.



WELD TPO OR PVC MEMBRANE TO COATED METAL STRIP.



USE SAND PAPER GRIT # 60 TO ABRASE THE AREAS TO WHICH THE LIQUISEAL LIQUID FLASHING RESIN WILL BE APPLIED.



THOROUGHLY CLEAN THE TIE-IN AREA.



CUT TWO PIECES OF [LIQUISEAL Flashing Fleece](#), (FOR DIMENSIONS SEE [LF-13.2A](#)).




APPLY PAINTER'S TAPE ALONG TIE-IN EDGE.



THOROUGHLY MIX THE RESIN, PER PUBLISHED INSTRUCTIONS.



INSTALL BOTH LAYERS OF PRE-CUT [LIQUISEAL Flashing Fleece](#), EMBEDDED IN RESIN (SEE [LF-13.2A](#)).



REMOVE TAPE IMMEDIATELY ENSURING THAT RESIN EXTENDS 1/4" - 1/2" BEYOND EDGE OF FLEECE.

<ul style="list-style-type: none"> <li>— ROOF MEMBRANE</li> <li>— LIQUISEAL Flashing Fleece</li> <li>— LIQUISEAL Liquid Flashing Resin</li> <li>0 — SEE NOTE(S)</li> </ul>	<p>TPO OR PVC MEMBRANE TIE-IN WITH EXISTING ROOF OVER STEEL DECK (PAGE 2 OF 2)</p> <p>For additional information, refer to Specifications</p>	<div> </div> <div> <p>DETAIL NO.</p> <p>LF-13.2</p> <p>LIQUID FLASHING</p> </div>
--	---	---