


1. REMOVE ALL GRAVEL AT TIE-IN.
2. SPLICE TWO PIECES OR MORE OF ELASTOFORM OR PRESSURE-SENSITIVE ELASTOFORM TOGETHER TO ACHIEVE DESIRED WIDTH.
3. IF FLUTES ARE PERPENDICULAR TO THE TIE-IN DRILL A 3/8" (1cm) DIAMETER WEEP HOLE ON THE BOTTOM FLUTES OF THE STEEL DECK ALONG THE PERIMETER TO THE TIE-IN 6" (15cm) FROM THE SEAM FASTENING PLATE.
4. ON MECHANICALLY FASTENED SYSTEMS, HP FASTENERS AND POLYMER SEAM PLATES ARE REQUIRED OVER STEEL DECKS.
5. IF WATER PONDS OR FLOWS OVER TIE-IN FROM BUR SURFACE, USE [DETAIL U-13B](#).
6. ON BALLASTED SYSTEMS, USE CONCRETE PAVERS TO PREVENT BALLAST MIGRATION.

DIMENSIONS	cm	
(A)	5"	13 MIN.
(B)	2"	5 ± 1/2" (1.5cm)
(C)	6"	15



BUILT-UP ROOFING TIE-IN OVER  
STEEL ROOF DECK

MAXIMUM WARRANTY: 30 YEARS



DETAIL NO.

U-13A

U (UNIVERSAL DETAIL)