



# Sure-Flex™ & FleeceBACK® KEE HP PVC Roof Families


KEE HP  
FULLY ADHERED



Sure-Flex™  
KEE HP




KEE HP  
MECHANICALLY  
FASTENED



Sure-Flex™  
KEE HP




KEE HP  
INDUCTION  
WELDED




Sure-Flex™  
KEE HP




Fleece  
KEE HP




FleeceBACK®  
KEE HP




KEE HP  
VEGETATED ROOF  
TRADITIONAL




Traditional Roof Garden  
With Sure-Flex™  
KEE HP PVC Membrane



FLEECE KEE HP  
VEGETATED ROOF  
TRADITIONAL



Traditional Roof Garden  
With FleeceBACK®  
KEE HP Membrane



## Standard Colors



### Revit Model Families Notes

#### General

The Revit model families provided contain multiple product selections for:

- Membranes
- Membrane Bonding Adhesives
- Coverboards
- Insulations
- Growth Media Depths (Roof Garden Assemblies Only)



Please select only one product for each of these layers to use and remove/delete the other products. This allows the customization of your roof assembly to meet your product selections.

### Choosing a Carlisle Roof Assembly Family for your project

1. Navigate to the Roof Assembly which you would like to use.
2. Click on the Family or square shown above the Isometric of the roof assembly.
3. Copy the family to your clipboard by selecting Ctrl + C on your keyboard.
4. Navigate to your project file you wish to import the family.
5. Paste the family from your clipboard by selecting Ctrl + V on your keyboard.
6. When creating a new roof, choose the Carlisle Roof Assembly from your choices of Roof Families.

### Editing the Family by Product Selection

1. Select the Family you wish to use, Adhered Assembly, Mechanically Fastened, etc.
2. Import the Carlisle Roof Assembly Family into your project.
3. In your project file, select the Carlisle Roof Assembly Family and double click, this opens the Family Property Box.
4. Open the Edit Construction tab within the Type Parameters Box.
5. Select the membrane(s) you are not using for your project from the list and click on it.
6. This highlights the selection. Click on Delete from the action buttons at the bottom of the list.
7. NOTE: This action will need to be repeated for each membrane deletion.
8. Repeat Step 5-7 for Membrane Bonding Adhesive, Coverboards, Insulations and Growth Media Depth, if using a Roof Garden Assembly Family.




### InsulFoam EPS Insulation Roof Family

#### Material Selection Notes:

1. InsulFoam EPS is not compatible with solvent-based adhesives. If solvent based adhesives are to be used, a coverboard must separate the membrane adhesive from the EPS insulation.
2. Flexible FAST™ (Low-Rise Polyurethane) Adhesive is compatible for direct attachment in Fully adhered systems between:
  - A. VapAir Seal MD/ 725TR air and vapor barrier (where used) and lower insulation layer
  - B. Structural Deck and lower insulation layers where air/vapor barrier is not utilized
  - C. EPS Insulation layers
  - D. Coverboards and insulation
  - E. FleeceBACK® membranes (excluding FleeceBACK® RL™ membranes) and coverboards/EPS insulation.
3. Coverboards must be used where InsulFoam EPS is the primary insulating roof board and Induction Welding is the membrane attachment method.

### Traditional Roof Garden Families Selection Notes:

1. Edit Core Boundary Roof Components as directed above.



2. Once growth media depth has been determined, delete extraneous growth media layers.

